

TRY 706

High visibility manikin



Dummy designed to provide effective training for the recovery of unconscious victims in water.

Specific Characteristics

Reinforced fabric where the dummy is more subject to abrasion

Equipped with pockets for floating foams storage. Removing the foams will change the floating attitude of the dummy in water

Supplied with boots to ensure protection if the manikin is dragged over beach or rocks

When the dummy enters the water the nylon mesh allows the water to rapidly penetrate the dummy. After a few minutes the legs of the dummy will drop below the surface, resting at an angle of about 45 degrees to the surface, the head and shoulder will be above the surface.

The color according to BS EN 471 and reflective labels, allow easy identification

Technical data

Manikin height	1,83 m
Materials	PU, polyester
Dry weight	40 kg
Wet weight	About 75 kg

TRY 706 - HIGH VISIBILITY MANIKIN

ST01901C

Distributed by Spencer Italia srl

Rev.1 (15/01/2018)

UNCHECKED COPY – further revisions will be available on <http://support.spencer.it>
 Spencer Italia S.r.l. Sala Baganza (PR) Italia Tel. +39.0521.541111 Fax +39.0521.541222

spencer.it