

JACK

Oleo-dynamic lifting trolley
With 4 steering wheels



Lifting trolley equipped with a foot operated hydraulic lifting system. It is ideal to handle and lift coffins without effort.

Specific features

- Robust and lightweight structure
- Large wheels for easy movement
- Mobile roller to facilitate the coffin's translation
- Parking brakes on rear and front wheels
- 4 steering wheel allow maximum maneuverability
- Quick and easy opening and closing
- Effortless lifting and linear height adjustment thanks to the hydraulic system
- Actuating pedal placed to ensure easy access and operation

Technical data

Width	630 ± 10 mm
Height raised	910 ± 10 mm
Height Lowered	420 ± 10 mm
Distance between supporting points when raised	800 ± 10 mm
Distance between supporting points when lowered	1110 ± 10 mm
Length raised	850 ± 10 mm
Length lowered	1140 ± 10 mm
Wheels	Ø 200mm
Weight	30,5 ± 0,5 kg
Loading capacity	270 kg
Material	Stainless steel, Nylon

Accessories

- | | |
|----------|---------------------------|
| ZC11000E | MEGA JACK (platform only) |
| ZC13000E | Pro Jack – basin for jack |

JACK LIFTING TROLLEY WITH 4
STEERING WHEELS Ø 200 MM
ZC10001C

Rev.2 (15/01/2018)

UNCHECKED COPY – further revisions will be available on <http://support.spencer.it>

Spencer Italia S.r.l. a socio unico Sala Baganza (PR) Italia Tel. +39.0521.541111 Fax +39.0521.541222

mortuary.spencer.it