

MEGA JACK

Oleo-dynamic lifting trolley with platform



Lifting trolley equipped with a foot operated hydraulic lifting system and equipped with platform for transport of heavy loads. It is ideal to handle and lift coffins without effort.

Specific features

- Extremely sturdy steel frame
- Large diameter wheels to increase sliding action
- The pedals are placed to make easier access and operation
- Parking brakes on two wheels
- Support with one roller to slide the coffin easier
- 20 rubber pads allow to absorb vibrations and limit unwanted movements of the load

Technical data

Minimum length	1120 ± 5 mm
Maximum length	1150 ± 5 mm
Lowered height	530 ± 5 mm
Lifted height	990 ± 5 mm
Width	635 ± 5 mm
Front wheels	∅ 200 mm with brake
Rear wheels	∅ 250 mm
Loading capacity	270 kg

MEGA JACK LIFTING TROLLEY WITH
LEVELLED PLATFORM

ZC12000E

Rev.0 (13/09/2017)

UNCHECKED COPY – further revisions will be available on <http://support.spencer.it>
Spencer Italia S.r.l. Sala Baganza (PR) Italia Tel. +39.0521.541111 Fax +39.0521.541222

mortuary.spencer.it